



**WizePanel™**  
**WizeScreen**

**(rev. 184)**

*Documentname: WizePanel\_WizeScreen\_V002  
(revision: 184, filesize: 57 kB)  
( created @ 26/04/2012 07:01:00 by Artur Wiebe)  
( last modified and saved @ 2012-05-25 13:32 by Artur Wiebe)*

*WTDN:*

*Wilke Technology GmbH  
Krefelder Str. 147  
52070 Aachen  
Germany*

*Phone: +49-241 / 918 900  
Fax: +49-241 / 918 9044  
Mail: info@wilke.de  
Web: [www.wilke.de](http://www.wilke.de)*

*Copyright © 2012 Wilke Technology GmbH. All Rights Reserved. All copyright and other intellectual property rights in this document are and shall remain the property of Wilke Technology GmbH. Unauthorized reproduction or distribution of this document, or any portion of it, may result in severe civil and criminal penalties and will be prosecuted to the maximum extent possible under law.*

## Inhaltsverzeichnis

1 Einleitung.....	5
2 Installation.....	5
3 Konfiguration.....	5
3.1 HTML.....	6
4 Historie.....	6

## 1 Einleitung

Der WizeScreen besteht immer aus einem Hintergrund-Bildschirm und wird über eine systemweit eindeutige Nummer identifiziert.

## 2 Installation

Entpacken Sie die ZIP-Datei in einem Verzeichnis ihrer Wahl. Speichern Sie ihre Lizenz-Datei als license.txt in diesem Verzeichnis.

## 3 Konfiguration

```
USAGE
[--full] [--sound <sound>] [--background <background>] [--config
<config>] [--wpid <wpid>] [--port <port>] [--debug] [--zoom]

[--full]
      Start the server in full-screen mode.

[--sound <sound>]
      Play soundfile after image has been set.

[--background <background>]
      Sets the image of the background screen.

[--wpid <wpid>]
      Sets the background WPID if no configuration file is
specified.

[--port <port>]
      HTML Server port (default: 9000)

[--debug]
      Start the server in debug mode.

[--zoom]
      Zoom all images to fit the screens completely.
```

Im einfachsten Fall wird das Programm auf der Kommandozeile folgendermaßen gestartet:

```
java -jar wizescreenserver.jar --wpid 10000 --full
```

Hiermit wird der WizeScreen im Vollbild gestartet und die WPID lautet 10000.

### 3.1 HTML

Der WizeScreen-Server (ab Version Januar 2012) hat eine HTML-Schnittstelle. Sobald der Server läuft, steht unter der Adresse <http://IP-ADRESSE:PORT/html/index.html> der aktuelle Bildschirm als HTML-Seite zur Verfügung. Der Bildschirm-Inhalt wird alle 5 Sekunden aktualisiert.

## 4 Historie

- Artur Wiebe, 25.03.2011 – Datei angelegt (Aus WizePanel\_Adapter\_V002.doc kopiert)
- Artur Wiebe, 04.01.2012 – HTML
- Artur Wiebe, 20.02.2013 – Neues Layout
- Artur Wiebe, 28.01.2015 – Neue WPID option